LAMINATE CLEANING & MAINTENANCE

LAMINATE CLEANING & MAINTENANCE

To clean Altispace Beams and Shapes, please follow our recommendations.

Dust and dirt on the panels and suspension hardware can be removed with a vacuum, and you can wipe off excess dirt or fingerprints by wiping them with a clean, dry and solf cloth. If this does not fully clean the panel, you can use a clean, damp and soft white cloth or sponge with a mild detergent to wipe down the beams, then rinse with warm water and wipe them dry.

For stains, use a clean, damp and soft white cloth or sponge with a mild detergent to clean off the stain, then rinse with warm water and wipe them dry. If the stain persists, use a paste of baking soda and water and apply it to the stain with a soft bristled brush. Use light scrubbing motions for 10 to 20 strokes. Baking soda is a low abrasive, and hard or excessive scrubbing can damage the laminate surface, so use caution with this step.

Stubborn stains that resist any of the above cleaning methods may require the use of undiluted household bleach or nail polish remover. Apply the bleach or nail polish remover to the stain and let stand no longer than two minutes. Rinse thoroughly with warm water and wipe dry. This step may be repeated if the stain appears to be going away and the color of the laminate has not been affected.

NOTES OF CAUTION

Steel wool and other abrasive pads will damage the laminate material, do not use them for cleaning your panels.

Hair dyes, textile dyes, and food dyes can cause permanent stains. If dye should happen to spill, wipe it up immediately with dishwashing detergent or an all-purpose cleaner.

Recommended Household Cleaners:

- Windex®*
- Glass Plus®*
- Fantastik®*
- Mr. Clean®*
- Formula 409®*
- Isopropyl Alcohol (Isopropanol)

When cleaning our laminated products, DO NOT use products that contain the following ingredients:

Chemical Ingredient	Synonomous Names
Hydrochloric Acid	Muriatic Acid Hydrogen Chloride
Sulfuric Acid	Oleic Acid Oil of Vitriol Oleum
Hydrofluoric Acid	Rust Remover
Phosphoric Acid	Rust Remover
Sodium Hydroxide	Caustic Soda Caustic Lye Soda Lye
Pumice (abrasive)	N/A



^{*}Prolonged exposure to bleach will cause discoloration.

ACOUSTIC

CLEANING & MAINTENANCE

ACOUSTIC CLEANING & MAINTENANCE

To clean Altispace Acoustic Blades, Acoustic Shapes, and Acoustic Fins please follow our recommendations.

Dust and dirt on the panels and suspension hardware can be removed with a vacuum or a stiff, plastic bristled brush. If using a vacuum, ensure the hose is clean.

For stains, apply a distilled water or a solution of carpet or upholstery shampoo to the stain and use a soft, clean and lint-free cloth to blot dry. If applying water directly to the product is not practical, a steam cleaner can be used. When using a steam cleaner, ensure that the steamer does not overheat the material.

